

Архангельск (8182)63-90-72
 Астана (7172)727-132
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16

Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
 Тверь (4822)63-31-35
 Томск (3822)98-41-53
 Тула (4872)74-02-29
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://mersen.nt-rt.ru/> || mnh@nt-rt.ru

Plug Fuses: G/GP/TD/GW/GTL/GT/GSL

Plug Fuses

UL/CSA LISTED POWER FUSES



Mersen Plug Fuses are for industrial and residential applications. Standard non-time delay fuses are for receptacle and lighting circuits. Standard time delay fuses are for motor loads. For Canadian requirements, a type "P" fuse is used for non-motor loads and type "D" fuses are used for electric heating and cycling loads circuits. Both fuses have low melting-point temperature elements. Low-Temp time delay plug fuses have thermal sensitivity are also for cycling loads and motor circuits. Type "S" plug fuses are time delay and tamper-resistant.

CATALOG NUMBERS (AMPS)

| Catalog Number | | | | | | |
|-------------------|--------------------|---------------|-----------------------------|------------------------|-------------------------|--------------------------|
| Edison Base | | | | | | Type S |
| Non-Time Delay UL | Non-Time Delay CSA | Time-delay UL | "P" Type Non-time Delay CSA | Low-Temp Time-delay UL | "D" Type Time-delay CSA | Rejection* Time-delay UL |
| GW3 | G3 | - | - | - | - | - |
| GW6 | G6 | - | - | - | - | - |
| GW10 | G10 | - | - | - | - | - |
| GW15 | - | GTL15 | GP15 | GT15 | TD15 | GSL15 |
| GW20 | - | GTL20 | GP20 | GT20 | TD20 | GSL20 |
| GW25 | - | GTL25 | GP25 | GT25 | TD25 | GSL25 |
| GW30 | - | GTL30 | GP30 | GT30 | TD30 | GSL30 |

FR15 Rejector Rings available

FRW Rejection removal tool available to remove FR15

*Must be used with an SAG adaptor to fit an Edison base fuse holder.

RATINGS:

- **Volts:** 125VAC
- **Amps:** 3 to 30A
- **IR:** 10kA I.R. AC
- Choice of Edison Base, Types "P," "D," or "S"

APPROVALS:

- UL Listed Guide JEFV, File E76208
- CSA Certified Class 142301, File 15525



TYPE S PLUG FUSE ADAPTORS

Type S adaptors screw into the Edison base and allow Type S fuses to be installed. Type S adaptors prevent the wrong ampere size fuse from being used.



| Cat.No./Rating | Fuse Range - Amps |
|----------------|-------------------|
| SAG3-2/10 | 1-8/10 - 3-2/10 |
| SAG6-1/4 | 3-1/2 - 6-1/4 |
| SAG15 | 7 - 15 |
| SAG20 | 20 |
| SAG30 | 25 - 30 |